

HINTS & TIPS CARDS

FZ200 Basic Setup Values for new users

My recommended setup values for the Panasonic Lumix FZ200 for most types of photography.

I recommend using **Aperture priority mode "A"** on the top control dial, then set the aperture to **F4** using the back control wheel.

Use ISO button set to **i.ISO** (use the top navigation button to access it)

Use back control wheel, click inwards to set the EV to **-1/3** (retain highlight)

In the **REC Menu** set the following conditions. (*All others camera default*).

Photostyle use **Standard and adjust to +1 sharpening and -1 noise reduction**

ISO Limit Set 400 (you can only set it the in Auto or i.ISO modes)

ISO increment 1/3EV *AF Mode* to Single area *AF style* to AFS

Quick AF to OFF *i.Dynamic* to OFF *i.Resolution* to OFF *Digital Zoom* to OFF

Motion Picture Menu

Rec Mode AVCHD

Rec Quality PSH

Continuous AF On

Zoom mic ON